


Wiring diagram for Wash v.2.1 installation:

Valid for versions with **numbered black cables** and also for versions with **unnumbered colored cables**.



Black cable no. 4 or gray cable: Phase cable of the general power supply line.

Cable n°5 or blue cable: Neutral cable of the general power supply.

Cable n°6 or pink cable: Positive cable of the Wash solenoid valve.

Cable n°7 or yellow cable: Negative cable of the Wash solenoid valve.

Cable n°8 or red cable: Positive cable of the Avatar power supply.

Cable n°9 or blue cable: Negative cable of the Avatar power supply.

Cable n°1 or green cable: Sensor connection cable.

Cable n°2 or white cable: Sensor connection cable.

Cable n°3 or brown cable: Sensor connection cable.

T - GND.